

RADIATOR STOP LEAK

COOLING SYSTEM ANTI-LEAK ADDITIVE

DISCRIPTION

Radiator Stop Leak is a fast-acting additive for the cooling system of water-cooled engines. The product stops and prevents leaks that can occur in the cooling system due to stone chips, porous seams and hairline cracks. Does not affect the proper flow of the refrigerant through the radiators.

CHARACTERISTICS

- Can be used preventively and curatively.
- Lubricates and protects the entire cooling system.
- Safe to use, permanent seal.
- Channels don't clog up.
- Compatible with all types of coolant and antifreeze.
- Prevents limescale in the cooling system.
- Protected against corrosion and oxidation.
- Lubricates the water pump and the heating taps.
- Guarantees good cooling.

APPLICATION

Suitable for all gasoline and diesel engines with water cooling.

OPERATING INSTRUCTIONS

Add one dose (400ml) to the cooling system of the car. For larger cooling systems, add 1 dose (400ml) per 8 - 10 litres.

The cooling circuit must be clean and free of limescale. If the cooling system is dirty, clean the cooling system first with RMC Radiator Flush.

Shake well before use. Add the product with running engine slowly to the cooling system via the radiator or the expansion tank while the coolant is circulating.

Attention: Do not add to a hot engine.

Contents: 12 x 400 ml/carton

